



9102-11 Kawasaki LED tail light Fits the Nomad 99-02, 1500/800 Classic 96-02

Note: The chrome base does not have to be removed from the fender.

Installation:

- Remove the red lens.
- Remove both light bulbs.
- Insert the bulb base from the LED replacement board into either bulb socket (Push in and turn clockwise). The base only goes in one way because of the offset posts on the base.
- Peel the red backing from the mounting tape on the bottom of the LED retro.
- Center the LED retro and push in place. The board is designed to fit tightly between the two screw posts.
- Hot glue should be used to further secure the LED in place.
- Replace red lens.

NOTE: These LED lights are not DOT approved and recommended for show or off road use only.